

Part D – Infection Control



Indian Health Facility Guidelines

Draft 1.2, July 2014

Table of Contents

1.0	General Requirements.....	3
1.1	General	3
2.0	Handwashing Facilities	4
2.1	General	4
2.2	Handbasin Types	4
2.3	Handwash Basins - Placement.....	4
2.4	Handwash Basin Types – Schedule.....	4
2.5	Work & Treatment Areas.....	5
3.0	Isolation Rooms	6
3.1	Class S – Standard Pressure.....	6
3.2	Class N - Negative Pressure	6
3.3	Class P - Positive Pressure	6
3.4	Class A - Alternating Pressure	6
3.5	Number of Isolation Rooms.....	6
3.6	Operating/ Procedure Rooms.....	6
3.7	Planning.....	7
3.8	Air-Conditioning	7
3.9	Cleaning Areas.....	7
3.10	Work Flows.....	8
4.0	Surfaces and Finishes	9
4.1	Floors.....	9
4.2	Skirtings	9
4.3	Walls	9
4.4	Ceilings.....	9
4.5	Gaps.....	9
4.6	Surface Materials	10
5.0	Construction and Renovation.....	11
5.1	Planning.....	11
5.2	Risk Management	11
5.3	Construction	11
5.4	Construction	12
5.5	Air Sampling Methodology	12
6.0	Verification	13
6.1	General	13



1.0 General Requirements

1.1 General

Infection Control requirements are critical to the planning of a Health Care Facility and need to be incorporated into plans and specifications.

All areas of the facility shall be designed, constructed, furnished and equipped in keeping with the principles of infection control.

Infection control involves the prevention of possible spread of infection by minimising the transfer of micro-organisms from person to person. Consider sufficient space to allow enough room for storage of Personal Protective Equipment (PPE) i.e. gowns and gloves for protective isolation.

A number of strategies contribute to the control of infection, such as handwashing, careful aseptic technique and the observance of 'standard precautions'.

By far the most important of the infection control strategies is effective handwashing. Hand-washing facilities shall be installed in all Patient Care Areas, and in all areas where careful attention to hygiene is essential, such as Kitchens, Laundries, Pharmacies and Laboratories. Staff Amenities Areas, such as Bathrooms, Toilets and Change Rooms shall also be equipped with hand-washing facilities. Refer to the heading 'Handwashing Facilities' for detailed requirements for staff hand-basins.

Facets of construction and fit-out that contribute to effective infection control are covered in various sections of these Guidelines. They include ventilation; floor coverings; waste management; provision for ease of cleaning; provision for sterilisation and disinfection of equipment and instruments; and provision for the isolation of infectious patients as required.



2.0 Handwashing Facilities

2.1 General

The Guidelines refer to several categories of hand basins including Type A, B, C and troughs along with various configurations for types and placement of tapware. These are addressed in the section and tables that follow.

2.2 Handbasin Types

Type A handbasin refers to a clinical scrub basin. The handbasin type is a large Clinical Scrub type. The taps are wall mounted, hands-free operation (elbow, foot or electronic). This basin is used in areas requiring clinical hand-washing for sterile procedures, for example ICU Rooms, Treatment Rooms and Cardiac Catheterisation areas.

Type B basin refers to a general staff handbasin. The basin type is a medium wall mounted basin. The taps are either wall mounted or basin mounted with hands-free operation (elbow or wrist). This basin is used in areas requiring general staff hand-washing, for example ward corridors.

Type C basin refers to a small staff handbasin. The basin type is a small wall mounted basin. The taps are either wall mounted or basin mounted with hands-free operation (elbow or wrist). This basin is used in areas requiring general staff hand-washing, for example Staff Amenities and Toilet Areas.

Scrub sink refers to a long sink that can accommodate one or more staff scrubbing for a sterile procedure at the one time. Refer to Ergonomics for the heights, width of space per person and type of taps.

2.3 Handwash Basins - Placement

Handwash Bays should be provided in the following ratios:

- Intensive/ Critical Care Units - one per enclosed room, one per two open Bays
- Emergency Unit - one per four open bays
- Ambulatory Care Areas - one per four open bays
- Other patient treatment areas - generally staff should not be more than 10 -12 metres from a Handwash Bay.

2.4 Handwash Basin Types – Schedule

Schedule of basin and tap types:

The following indicates recommended basin and tap combinations for particular rooms. For rooms not listed refer to a similar area.

ROOM / SPACE	Basin Type	Wall Tap	Basin Tap	Wrist Action	Elbow Action	Infra-red	Remarks
BAY - HANDWASHING	B	Yes	Optional		Yes		In Corridors
BATHROOM	B		Yes	Yes			
BIRTHING ROOM	A	Yes			Yes	Optional	
CLEAN UTILITY	B	Yes	Optional		Yes		
CLEAN-UP ROOMS	B		Yes	Yes			
CONSULT ROOM	B	Yes	Optional	Yes	Yes		Also, includes Exam Rooms
DIRTY UTILITY	B		Yes	Yes			



ROOM / SPACE	Basin Type	Wall Tap	Basin Tap	Wrist Action	Elbow Action	Infra-red	Remarks
ENSUITES	b		Yes				
HIGH DEPENDENCY UNIT	A	Yes			Yes		
INPATIENT BEDS	B	Yes			Yes		
INTENSIVE CARE UNIT	A	Yes			Yes		
ISOLATION ROOM - AIRLOCK / ANTEROOM	B	Yes			Yes		
ISOLATION ROOM/ S PANTRY		Yes	Yes		Yes		Includes Kitchenettes, Beverage Pantry
POST MORTEM		Yes	Optional		Yes		
RECOVERY		Yes			Yes		
SCRUB-UP / GOWNING		Yes				Yes	Operating Unit, Day Procedure Unit, Procedure Rooms including Imaging
TOILET - PATIENT			Yes				
TOILET - PUBLIC			Yes				
TOILET - STAFF			Yes				
TREATMENT ROOM		Yes			Yes		

2.5 Work & Treatment Areas

Sinks should not be provided in Clean Utility areas to avoid the risk of contamination of sterile stock stored in this area. The clinical handbasin should be located external to the room. Basin Type B is recommended for this area.



3.0 Isolation Rooms

3.1 Class S – Standard Pressure

Recommended elements for Class S Isolation Rooms are as follows:

- A staff handbasin within the room
- An Ensuite Bathroom
- A self-closing door.

A pan sanitiser located near the room is an optional element for Class S Isolation Rooms.

3.2 Class N - Negative Pressure

Negative Pressure Rooms are for patients who require airborne droplet nuclei isolation. The aim of placing persons in Negative Pressure rooms is to reduce transmission of disease via the airborne route.

For elements and inclusions for Class N Negative Pressure Rooms, refer to Department of Human Services Isolation Room Guidelines.

3.3 Class P - Positive Pressure

For elements and inclusions for Class P Positive Pressure Rooms, refer to Department of Human Services Isolation Room Guidelines.

3.4 Class A - Alternating Pressure

Rooms with reversible airflow mechanisms, which enable the room to have either negative or positive pressure shall **NOT** be used.

3.5 Number of Isolation Rooms

A minimum of 20 % of the total bed complement in Inpatient Accommodation Units (across the whole facility) used for overnight stay shall be provided as Single Bedrooms (Type S).

All HPUs providing inpatient overnight accommodation shall provide at least one 'Class S - Standard' Isolation Room.

All facilities at Level Four and above shall provide at least one 'Class N - Negative Pressure' Isolation room per 100 overnight beds. Additional 'Class N - Negative Pressure' Isolation Rooms may be required to meet service profile and model of care for the HPU and the facility.

The provision of 'Class P - Positive Pressure' Isolation Rooms are only required to meet the requirements of the service profile and the model of care for the HPU and the facility.

3.6 Operating/ Procedure Rooms

When bronchoscopy is performed on persons who are known or suspected of having pulmonary tuberculosis, the Operating/ Procedures Room shall meet the Negative Pressure Isolation Room ventilation requirements.



3.7 Planning

The design of the premises is fundamental to infection control and implementation of 'Standard' and 'Additional' precautions. All new or renovated Health Care Facilities should incorporate in their design and layout the physical requirements that are essential for an infection control strategy.

The design of the premises should consider the movement of people and equipment in ways that minimise the risk of transmission of infection.

3.8 Air-Conditioning

Hospital air-conditioning systems should be monitored regularly and serviced by accredited service technicians. Maintenance schedules should be documented.

Air-conditioning or ventilation systems in critical areas such as Operating Rooms, Birthing Rooms, Tuberculosis isolation rooms, Burns Units, Intensive Care Units, Emergency Units, as well as in special treatment or procedural areas, should provide high quality air at all times.

Where the Sterile Supply /

Service Unit is attached to Operating Rooms, ventilation should be provided by a treated air supply and air-conditioning should comply with Part E of these Guidelines. Air-conditioning in separate Sterile Supply / Service Units should comply with the relevant Standards.

Where there is a risk of airborne transmission of pathogenic micro-organisms, there should be a sufficient number of single rooms (at least one per 100 Beds) with adequately filtered air-conditioning which should have external exhaust systems. No recirculation of air should be permitted. For tuberculosis isolation and treatment rooms, negative pressure ventilation should be made available, in accordance with nationally endorsed guidelines, and State and Territory tuberculosis guidelines. A minimum of twelve air changes per hour (ACH) are advised, including at least two outside air changes per hour, plus good air circulation within the room.

3.9 Cleaning Areas

Separate and clearly defined operating and cleaning areas are required to maintain adequate barriers for infection control. Delineation of these areas facilitates easy identification of surfaces that should be cleaned and disinfected between patients. Both areas should have adequate lighting, good ventilation to reduce the risk of cross-infection from aerosols, bins for the disposal of hazardous waste and smooth impervious surfaces without crevices.

The cleaning area should be divided into a contaminated section and a clean section.

The contaminated section shall comply with AS4187 and include:

- Adequate bench space for dismantling and working on equipment
- At least one deep sink or trough (stainless Steel) for manual cleaning of instruments and other equipment
- Cleaning and disinfecting materials
- Cleaning and disinfecting equipment including brushes
- Steriliser
- Mechanical disinfector / washer.

Cleaning sinks must be located separately to clinical hand washing basins to avoid risk of contamination and must be used only for decontamination of equipment and instruments. Where filters are fitted to taps in place of antisplash devices, they should be cleaned regularly. In office practices where there are no surgical or dental procedures being carried out, for example, in acupuncture clinics, a stainless steel or smooth hard plastic bowl dedicated to use in the cleaning and decontamination of instruments and devices, may be used as an alternative to a sink for cleaning.



The processing area should be carefully defined and protected from all vapours, splashing or aerosols produced during operating, hand-washing, equipment washing, disinfection and ultrasonic cleaning. The area should have adequate storage space and be used only for the storage of effectively covered or packaged cleaned, disinfected and/or sterilized instruments and equipment.

3.10 Work Flows

Staff eating and recreation areas must be separate from work areas and patient treatment areas.



4.0 Surfaces and Finishes

4.1 Floors

Treatment Areas should not be carpeted. Vinyl is to be located under all hand wash basins. The flooring should be easily cleaned and in good repair.

Floors in areas used for food preparation or food assembly shall be water resistant and greaseproof to comply with the Food Hygiene Regulations. Floor surfaces, including joints in tiles in such areas, shall be resistant to food acids (epoxy grout). In all areas subject to frequent wet cleaning methods, floor materials shall not be physically affected by germicidal cleaning solutions.

4.2 Skirtings

Wall bases in Kitchens, all clinical areas and other areas subject to frequent wet cleaning methods shall be made integral with the floor, tightly sealed against the wall, and constructed without voids.

4.3 Walls

Other than special treatments included as feature face work in public or staff relaxation areas, wall finishes in clinical areas shall be scrubbable with smooth surfaces, and in the immediate vicinity of plumbing fixtures, shall be smooth and water-resistant.

4.4 Ceilings

All exposed ceilings and ceiling structures in areas occupied by patients or staff, and in food preparation or food storage areas, shall be finished to be readily cleanable with equipment routinely used in daily housekeeping activities.

In food preparation and other areas where dust fallout would present a potential problem such as clinical areas, supply and storage areas and sterile stock storage, there shall be a finished ceiling that covers all conduits, piping, duct work and open construction systems.

Ceilings in Operating and Birthing Rooms, Isolation Rooms, Nurseries, Sterile Processing Rooms, Bone Marrow Transplant Units and Oncology Units shall be monolithic from wall to wall without fissures, open joints or crevices that may retain or permit passage of dirt particles. Light fittings shall also be recessed and flush fitting and sealed to prevent dust ingress.

Acoustic and/or lay-in ceilings shall not be used where particulate matter may interfere with infection control.

4.5 Gaps

A gap is defined as a space where two materials do not meet leaving a space or opening that can harbour dust, germs, mould or vermin.

In the construction of Health Care Facilities, gaps between surfaces are not permitted, and must be properly sealed. In particular, gaps in the following area are not allowed:

- Between skirting and floor
- Between utility benches and walls
- Between cupboards and floor or walls
- Between fixtures attached to floors and walls.



Floor and wall construction, finishes and trims in dietary and food preparation areas shall be free of spaces that can harbour rodents and insects. Details to comply with the relevant Public Health regulations.

Floor and wall penetrations by pipes, ducts and conduits shall be tightly sealed to minimise entry by rodents and insects. Joints of structural elements shall be similarly sealed.

4.6 Surface Materials

Regular routine cleaning of the Health Care Facilities premises can be carried out much more efficiently if the design of the building is adapted to its function. Unnecessary horizontal, textured, moisture retaining surfaces or inaccessible areas where moisture or soil will accumulate should, if possible, be avoided.

All fixtures and fittings should be designed to allow easy cleaning and to discourage the accumulation of dust. Blinds are preferable to curtains for this reason.

Where there is likely to be direct contact with patients, or with blood or body fluids, floors and walls should be surfaced with smooth, impermeable seamless materials, such as vinyl. In equipment processing areas, work surfaces should be non-porous, smooth and easily cleaned.

All surfaces in high risk clinical areas, including the Operating Unit, Intensive Care Unit, Obstetrics Unit and Neonatal Special Care Nurseries, should be smooth and impervious.



5.0 Construction and Renovation

5.1 Planning

Infection control precautions during construction should be integrated into the design and documented from the beginning of the design stage. It is important that the dust and infection control principals developed during the pre-design stage are integrated at the initial stages of the design development. It is important that the pre-design team comprehensively brief the design team and submit the findings of the survey and risk profile.

5.2 Risk Management

A formal approach to risk management must be part of all building and renovation activities. Risk management should include specific assessment of infection control risks.

A more detailed review of risk is beyond the scope of this document, but adherence to Risk Management principles will provide the framework to assemble a relevant risk management strategy.

Airborne sampling may be part of a risk management program. Cumulative data is used to establish indoor and outdoor background levels of filamentous fungi for a particular site. This will enable establishment of risk profiles for particular locations in and around the hospital.

The risk profile should as a minimum:

- Identify the location of high-risk patients in relation to the site
- Identify ventilation system types and potential impact
- Determine air monitoring requirements, methodology and frequency
- Take air quality samples to establish a baseline
- Identify possible contaminants and their locations (contaminants may be present in ceiling dust, service shafts, sprayed on fire retardants and bird droppings).

5.3 Construction

Current construction practices can affect patient well being by the dissemination of bacteria and fungi that can cause health care associated infections.

Building, renovation and maintenance activities within a Health Care Facility impose risks upon the incumbent population unlike any other building site.

Building practices therefore require a range of precautions appropriate to the risk. Identification of the at risk population, a knowledge of the transmission route of a likely pathogen and location of the at risk population in relation to the construction, all need to be taken into account in the planning stages.

Infection control measures to consider during construction are:

- Infection control site induction of building workers should be carried out as a major component of the OH&S induction. This induction process should be documented and signed off by each person inducted
- Worker compliance with procedures should be monitored and the results of this monitoring should be fed back to the workers routinely through the Builder. A system must be in place to manage major breaches.
- Ensure that adequate inspections by the nominated representatives take place during the construction of the barriers. These inspections should be monitored and reported on.



5.4 Construction

Negative pressurisation of the construction zone is recommended to maintain correct airflow direction. The exhaust/extraction systems specified in the contract documentation must be constantly monitored and maintained to ensure no failures occur. These inspections should be documented and reported on.

If HEPA filtration is required, a person must be nominated as the responsible person for that duty. The filters should have differential pressure monitoring with alarms. Spare filter elements must be kept on hand. These inspections should be documented and reported on.

Routine inspections of barriers should be conducted by the hospitals nominated representative from the contractor. These inspections should be documented and reported on.

Routine air sampling should be employed by the hospital to monitor the effectiveness of the barriers, pressurisation and housekeeping procedures. The routine air sampling should be documented and reported on.

A high level of site cleanliness is essential. It is recommended that tools with efficient dust extraction systems connected to HEPA filters are to be used. Tasks such as sanding plasterboard present a high level of potential risk. Therefore, it is recommended that mechanical sanding should be used.

Demolition and jack hammering of concrete should be undertaken with a filter unit in close proximity.

HEPA vacuuming, not sweeping, should be used to clean up. Conventional vacuum cleaners disseminate huge quantities of dust and fungal spores and should not be used.

Movement in and out of the site shall be controlled by restricting access to only those who have undergone site induction. This will assist greatly in reducing the spread of contaminants.

All inspections should be documented including a non-conformance system for defaults complete with a corrective and preventative action loop.

5.5 Air Sampling Methodology

There are two distinct sampling methodologies for the detection of viable airborne fungal spores. These are high air volume sampling and low air volume sampling. Sampling for viable fungal spores almost universally is via low air volume sampling. Low volume sampling is used to measure high spore concentrations. High volume sampling is used to measure low spore concentrations.

Along with airborne sampling, routine surface sampling should be used. A combination of settle plates and surface swabbing can be employed to augment airborne sampling. Airborne sampling has limitations due to the burst nature of fungi and the transience of bacilli.

It is important to have a clear idea of what outcomes are required of the sampling. Equally important it is necessary to have an approximate idea of the expected number of fungi that will be obtained. This will determine the appropriate sampling system.



6.0 Verification

6.1 General

All infection control measures described in this section are required to be capable of verification by inspection. There must be no barriers in place to prevent the checking and validating the measures described.



The Indian Health Facility Guidelines recommends the use of **HFBS** “**Health Facility Briefing System**” to edit all room data sheet information for your project.

HFBS provides edit access to all HFG India standard rooms, departments, and more than 40 report templates.

HFBS Health Facility Briefing System



Briefing Module

The Health Facility Briefing System (HFBS) has numerous modules available via annual subscription. It suits healthcare Architects, Medical Planners, Equipment Planners Project Managers and Health Authorities.

Use the HFBS Briefing Module to quickly drag in health facility departments or pre-configured room templates from the HFG standard, edit the room features such as finishes, furniture, fittings, fixtures, medical equipment, engineering services. The system can print or download as PDF more than 100 custom reports including room data sheets, schedules, and more...

To learn more about the HFBS web-based Healthcare Briefing and Design Software and to obtain editable versions of the “Standard Components” including Room Data Sheets (RDS) and Room Layout Sheets (RLS) offered on the HFG website, signup for HFBS using the link below.

Get Started Now:
hfbs.healthdesign.com.au

- ✓ HFG India Room Data Sheets and Departments are instantly editable in the HFBS software available online in the HFBS India Domain.
- ✓ You can access hundreds of report templates to print your HFG India room data in HFBS.
- ✓ HFBS has a onetime free 3 day trial available to all new users – signup for the HFBS India Domain today.

Get Started Now:
hfbs.healthdesign.com.au



HFBS

Health Facility Briefing System

hfbsinfo.com | techsupport@healthdesign.com.au